

Valued Customer,

Here are some text instructions we have prepared to assist you in assembly. Please do not hesitate to call if we can be of further assistance.

Your Team at Bird Cages 4 Less!
1-888-CAGE-4-LESS (224-3453)

Banyan Line Dome Top Assembly Instructions:

1 - Main Assembly:

Assemble the four main panels (front, back and sides). The side panels have threaded inserts so you do not need nuts for this. Align the front panel with one side and insert bolt through front panel into insert in side panel. Repeat for all four sides. You can put the panel with the two feeders on either side.

2 - Feeders:

Attach the feeder rings to the feeder doors. The bracket on the feeder ring is threaded so again you do not need nut. Place the short stubby bolt though the outside of the feeder door and place the feeder ring on the inside - the bolts will thread right into the bracket - then insert bowls.

3 - Top:

The top section is composed of two pieces There are two fixed bolts at the top of each side panel - the bottom of the top pieces fit over these. Then you put two bolts in through the front and back panel into the top of the dome pieces (these have threaded inserts also).

4 - Seed Guards:

You will see four clips. These are not necessary. The seed guards used to be attached with these, but now there are holes to bolts the seed guards together with (the clips would always loosen and fall off). First insert the see guard posts in the corresponding holes on the horizontal bracket - the seed guards should be placed so that the lip is down (smooth end up). Tilt the seed guards up until they meet at the corner and then bolt together (small bolts and nuts).

5 - Casters:

Casters either bolt in or slip into the inserts in the legs (depending on the style you have).

6 - Misc.:

Grate and pan slide in on runners.

7 - Lock:

Install the lock with the piece with the handle on the door.

Enjoy your cage!

Copyright©2010 Bird Cages 4 Less®