Valued Customer,

Here are some text instructions we have prepared to assist you in assembly. Please do not hesitate to call if we can be of further assistance.

Your Team at Bird Cages 4 Less! 1-888-CAGE-4-LESS (224-3453)

Lava Line Playtop (Pili, Lani Kai, Kauai, and Kilauea) Assembly Instructions:

Hardware (may be some extra):

- 12 main assembly bolts

- 4 bolt in casters
- 8 small bolts and nuts for seed guards

- 8 brass pins (for seed guard installation - may be removed once seed guards are installed)

- 6 bolts for ladders and top perch (two larger bolts with nuts to attach wooden perch to support)

- 3 feeder brackets and attached hardware (cage interior)

- 5 stainless steel bowls (3 interior (2 for Pili and Lahaina) - 2 playtop)

1 - Assemble the four main panels (front, back and sides). The front and rear panels have threaded inserts so you do not need nuts for this. Align the front panel with one side panel and insert bolt through side panel into insert in front panel. Repeat for all four sides. You can put the panel with the two feeders on either side. Note that if one person is putting the cage together, it is easier to lay the back panel on the floor, attach each side, attach the front and the casters. and then stand the cage up for the remainder of the assembly.

2 - Attach the feeder rings to the feeder doors. Then insert bowls.

3 - Top Section: place top grate on top of opening - it sets in a little. Please the tray above the grate. Bolt the ladders to the front and rear panels (two bolts on each end of ladder - no nuts necessary for this). Bolt the perch support to the top of the ladders (the bolts threads in to the bottom of the perch support through the hole in the tab in the top center rung of each ladder). The wooden perch may already be bolted to support - if not use 2 larger bolts with nuts). If holes on ladders, support and perch do not line up, switch the ladders end for end, switch the perch, etc., and they will line up.

4 - You will noticed eight brass pins with a bend at one end. Insert the end with the bend into the holes along the horizontal support beam where the lower pan slide in (two on each side). Once all eight are in place, set the seed guards on top of them (the longer seed guards go on the front and rear). The only purpose of the pins is so that one person can bolt the seed guards together without assistance. Once the seed guards are in place (lip is down - smooth end up), tilt the seed guards up until they meet at the corners and then bolt together.

5 - Casters bolt in to legs on front and rear panels.

6 - Lower grate and pan slide in on runners.

Enjoy your cage!